

DuPont & Rapak Product Bag Installation Instructions

DuPont Liquid Packaging Systems Flip-Cap Instructions

1. Flip bag over and place into the product bin (SPOUT SIDE DOWN).
2. Make sure the spout (fitment) is pushed all the way down into the keyhole and the bag is distributed to all 4 corners of the bin.



3. Lock the spout in place below the locating nubs.



4. Grab the finger tab located in the center of the shipping cap and pull outward.



5. Swing the shipping cap back out of the way to the side. This will clear the way for the mix inlet fitting to enter the cap.




Rapak Product Bag Installation Instructions

1. Insert the product bag into the product bin (SPOUT SIDE DOWN) and line up the clear spout to the keyhole.



2. Pull the 4 corners of the bag to the 4 corners of the product bin. Lock the clear spout in the keyhole with the guillotine.




3. Remove the protective dust cover.



4. Insert the product bin into the machine with the dust cover removed. Gently place into an engaged position in the BIM.


KEY HANDLING STEPS

PASOS PRINCIPALES PARA EL USO



Place bag in tray spout side down.

Coloque la bolsa en la bandeja con la boquilla hacia abajo.



Place bag so 4 corners are up, in the corners of the tray.

Coloque la bolsa con las 4 esquinas hacia arriba, en las esquinas de la bandeja.



Position rear groove of fitment into slot of product bin. Ensure the fitment is properly snapped into place.

Ubique el canal posterior del mecanismo en la ranura del recipiente del producto. Asegúrese de que el mecanismo encaje correctamente en su lugar.

Gently press spout into the engagement position. Open the cap on the product bag and tear it off.

Presione suavemente la boquilla en la posición de acoplamiento. Abra el tapón en la bolsa del producto y arránquelo.